
**EFFECTIVE: MARCH 2011** 

## American Dish Service

ADS LOW TEMPERATURE DISHWASHER **MODEL: 5-CD LF/RF** 




## PARTS MANUAL 900 Blake Street Edwardsville, Kansas 66111 (913)422 3700

(913)422-3700



The American Dish Service part numbers contained in this publication are replacement parts for equipment listed with governmental and regulatory agencies and are specified to maintain the regulatory mark and certification. These parts must only be replaced by those who are trained in the operation and service of commercial dishmachines. Aftermarket parts or modified parts are not compliant or listed with the standards of governmental and regulatory agencies; aftermarket parts are not authorized by ADS for replacement repairs. ADS will not be responsible for any liability If parts are used in the repair of the machine that are not ADS-specified, by those installing non-certified replacement parts or attempts to change the machine's cycle or operation other than as designed and certified. Read the warnings and cautions provided below before working on or replacing parts on any ADS equipment.





The installation of electrical parts contained in this publication require the following precautions:

The electrical power supplied to this machine is an imminent hazard to life that could result in severe bodily injury or death if not properly installed or connected correctly. When working in the control box or on electrical parts, always disconnect power and perform the appropriate lock-out/tag-out proceedure before servicing. Replace the cover to the control box and other protective covers when finished with servicing this equipment before returning the machine to normal operation.

**LOOSE ELECTRICAL CONNECTIONS**: Damage to the equipment can occur if the following precautions are not observed. Before connecting power to the machine, check all electrical terminals in the control box. Screws can loosen in transit. Loose connections on high amp load terminals such as the pump motor and tank heaters will cause wire burning and component damage during operation and will not be covered under ADS warranty.

"CLEAN CIRCUIT" means the electrical circuit breaker for the dishmachine supplies no other outlets, machines, or lights. GFCI outlets are not recommended for commercial dishmachines; ADS recommends that a single-rack machine be installed with the wire connection (hard-wired) directly from the circuit breaker. All high temp and conveyor equipment must be hard wired. If a plug and socket are used to provide electrical power to a dishmachine in a commercial kitchen, then according to electrical code it must be a GFCI, but not all GFCIs are the same. They must be rated for the Amp draw for the designed circuit.

For Reference: The NEC Article 210.8 regarding GFCI Protection (B) Other Than Dwelling Units (2) Commercial and Institutional Kitchens. All 15 and 20A, 125V receptacles installed in kitchens, even those that do not supply the countertop surface, must be GFCI protected.





The chemical feeders and controls contained in this publication require the following precautions:

**READ Manufacturer's Manual before Using this Product. For your safety read and observe all warnings in these instructions.**While performing installation of parts described in this booklet, wear approved Personal Protective Equipment, including chemically resistant gloves and Safety Eye-Wear.

**CHEMICALS**: There are potentially hazardous situations when working with industrial cleaning chemicals for dishmachines. See chemical manufacturer's safe practices and SDS or MSDS sheets for handling and installing chemicals and supply containers.

Chemicals can damage or corrode plumbing and stainless parts of the dishmachine. Do not run chemical lines over controls or plumbing. Always secure chemical lines and check regularly for leaks. If not properly handled, chemicals can cause serious bodily injury. In the event of chemical contact to skin or eyes; wash immediately with fresh water and seek medical

DE-LIMING THE MACHINE: Because of potential hazards resulting from the combination of chlorine with acid solution, only authorized trained individuals must be allowed to de-lime a commercial dishmachine.

CONTAINERS: The ADS chemical delivery system is designed for 5 gallon pails of industrial low-energy chemical products. Always use chemical resistant safety gloves and safety goggles (indirect-vented or non-vented) when changing chemical

CONTAINERS: The ADS chemical delivery system is designed for 5 gallon pails of industrial low-energy chemical products. Always use chemical resistant safety gloves and safety goggles (indirect-vented or non-vented) when changing chemical buckets. Immediately report spills and refer to your chemical suppliers SDS safety data sheet or MSDS material safety data sheet for information if chemical comes in contact with skin or eyes.

Any modifications to the chemical delivery system for smaller containers must include Closed Loop Chemical Containers (spill proof bottles) in a secured racking system. It is the responsibility of the user of the machine to purchase chemicals in spill proof containers. <a href="FAILURE CAN RESULT IN SERIOUS INJURY">FAILURE CAN RESULT IN SERIOUS INJURY</a>. Never place chemicals in open containers or containers that can be easily tipped over when moving or changing product. Failure to do so will void your ADS warranty.

Chemical supplies must be kept in closed delivery containers to avoid spills or contamination. Do not place chemical solutions in open containers or containers that can be easily tipped over in moving or changing.

Do not open the doors while the machine is in operation. Doing so could result in serious bodily injury from spraying hot water and chemicals.



#### CAUTION

The door lever arm parts in this publication are installed under spring tension and caution is needed whenever parts are changed. Wear safety glasses when working on the doors and lever. Care should be taken when moving, installing, or replacing any door lever arm parts. Use the ADS lever arm tool to unload the door spring during replacement or adjustment. The spring tension suddenly released can result in pinch or blunt trauma, and puncture wounds. If a wound occurs from the release of spring tension, wash the wound area immediately because of the soils that can accumulate on the metal parts and seek medical attention.

#### NOTICE

BEFORE YOU BEGIN: American Dish Service provides this information as a service to our customers. Keep all instructions for future reference. ADS reserves the right to alter or update this information at any time. Should you desire to make sure that you have the most up-to-date information, we would direct you to the appropriate document on our web site:

www.americandish.com. It is your obligation as the customer to ensure that the replacement parts for the machine are installed safely and properly, and when completed, the machine is left in proper and safe working order. Electrical, Plumbing, and Chemical hookup must be performed by a qualified professional who will ensure that the equipment is installed in accordance with all applicable Codes, Ordinances, and Safety requirements. Failure to follow the installation instructions will void the warranty. ADS assumes no liability or control over the installation of the equipment or replacement parts. Product failure due to improper installation is not covered under the ADS Warranty.


#### Plumbing parts:

When working on the water inlet manifold, first relieve the water line pressure by turning off the water supply to the machine then energize the machine's fill valve. By doing this the manifold will empty of water. Turn off the electrical power and lock out/tag out the machine. It will then be safe to open the plumbing inlet manifold.

**TANKLESS WATER HEATERS** have shown to be problematic for commercial dishmachines. It has been the experience of ADS that tankless supply systems require multiple units plumbed in sequence with a recirculation loop to achieve proper pressure and temperature.


Check with the tankless water heater manufacturer, they may recommend a storage tank to guarantee proper flow and line pressure to the machine. Failure to provide adequate water quantity, pressure and temperature to the machine will cause the machine to function improperly and is not the responsibility of ADS. Improperly installing ADS equipment or parts in this manner could void the warranty. All costs associated with providing an adequate water supply to the machine is the sole responsibility of the user.

Drain replacement parts should not be reduced in size, all drain lines should remain the same size as it exits the dishmachine or larger. If you have questions, call 800-922-2178 or visit our website at <a href="https://www.AmericanDish.com">www.AmericanDish.com</a>




Ref.	Dort No.	No.	Description
No.	<b>Part No.</b> 061-2100	<b>Req.</b> 1	Description Cobinet Assembly F CD L F
- 1			Cabinet Assembly, 5-CD LF
2	061-2200	1	Cabinet Assembly, 5-CD RF
2	064-2800	1	Control System Assembly, 5-CD LF/RF
3	066-1700	1	Drain System Assembly, 5-CD LF
4	066-1800		Drain System Assembly, 5-CD RF
4	063-2200	1	Recirculating Pump Assembly, 5-CD LF
	063-2300		Recirculating Pump Assembly, 5-CD RF
5	051-9001	1	Scrap Trap Weldment, 5-CD LF/RF
6	065-2100	1	Fresh Water Plumbing Assembly, 5-CD LF/RF
7	062-1800	2	Spray System Assembly, 5-CD LF
	062-1900		Spray System Assembly, 5-CD RF
8	067-1400	1	Door Actuator Assembly, 5-CD LF
	067-1500		Door Actuator Assembly, 5-CD RF
		1	1

#### 061-2100/061-2200 CABINET ASSEMBLY LF/RF 5-CD




### 061-2100/061-2200 Cabinet Assembly LF/RF American Dish Service 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	085-6415	1	Frame, LF
	085-6416		Frame, RF
2	085-6417	1	Pan, LF
	085-6418		Pan, RF
3	087-6116	1	Door
4	085-6419	1	Hood, LF
4A	085-6420		Hood, RF
5	083-6108	4	Doorstrip, Clear
6	087-6124	1	Door, Front
7	087-6114	2	Door Guide
8	087-6118	1	Door Guide, Front Corner
9	085-6421	1	Tray Track Assembly, LF
9A	085-6422		Tray Track Assembly, RF
10	098-2507	40	Locknut, 1/4-20, SS
11	098-2404	40	Washer, ¼", SS
12	098-1423	40	Bolt, 1/4-20 x 1/2", HH, SS
13	099-1003	4	Bullet Foot
14	089-9055	1	Scrap Trap
15	089-9100	1	Scrap Trap Lid
16	086-6419	1	Chemical Bracket, Top Mount
17	089-9056	1	Scrap Trap Tray
N/S	086-6685	1	Bracket, 5CD Tray Track Support
N/S	087-6389	1	Front Guide, 5CD Tray Track




#### 062-1800/062-1900 Spray System Assembly LF/RF 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	085-6628	2	Upper Spray Base, SS, Thumbscrew Type
1A	085-6626	Opt.	Upper Spray Base, SS, Bayonet Type
2	098-1583	12	Thumb Screws 5/16-18 x 5/8" SS
2A	099-1028	Opt.	Bayonet Fitting
3	098-1426	8	Bolt, 1/4-20 x 3/4" HH SS
4	098-2507	16	Locknut, 1/4-20 SS
5	081-6214	4	Spray Arm Assembly
6	081-6210	4	Spray Arm Bearing Assembly, Cleanable
7	087-6233	1	Upper Arm Supply Tube (Manifold)
7A	087-6234	1	Upper Arm Supply Tube (Manifold) LF, LH
8	081-6501	4	Clamp Assembly, Inside Manifold (Incl. Bolts & Nuts)
9	098-1426	8	Bolt, 1/4-20 x 3/4" HH SS
10	084-6211	8	Spray Arm End Plug, SS
11	085-6633	1	Lower Spray Base, SS, Thumbscrew Type, RH
11A	085-6632	1	Lower Spray Base, SS, Thumbscrew Type, LH
11B	085-6631	Opt.	Lower Spray Base, SS, Bayonet Type, RH
11C	085-6630	Opt.	Lower Spray Base, SS, Bayonet Type, LH
12	093-1040	2	Kit, Discharge Tube
13	089-6201	2	Gasket, Spray Base
14	098-2404	8	Washer, 1/4", SS
15	093-1041	4	Plastic Sleeve, Inside Manifold Tube
16	098-1445	8	Bolt, 1/4-20 x 1" HH SS




# 063-2200/063-2300 Recirculating Pump Assembly LF/RF 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	091-1001	1	Motor
2	082-6301	1	Rear Housing
3	092-2001	1	Seal Assembly
4	082-6305	1	Impeller, 7-vane
5	089-6303	1	Gasket, Pump
6	082-6302	1	Front Housing (Pump Cover)
7	085-6325	1	Discharge Pipe 'T' Weldment
8	092-1144	1	Pipe Plug, 3/8", SS
9	092-1002	1	Petcock 1/8"
10	092-1145	1	Pipe Plug, 1/8", SS
11	098-1507	2	Bolt, HH, SS, 5/16-18 x 7/8
N/S	098-1510	2	Bolt, 5/16-18 x 1 1/4", HH, SS
12	098-2503	4	Washer, Copper 5/16
13	098-1607	4	Bolt, 3/8-16 x 7/8" HH SS
14	085-6321	1	Pump Pipe, Suction
15	093-1039	2	Kit, Suction Tube
16	085-6326	1	Suction Tube, LF
16A	085-6327		Suction Tube, RF
17	098-1426	2	Bolt, 1/4-20 x 3/4", HH, SS
18	085-6408	1	Motor Plate
19	098-2404	6	Washer, ¼", SS
20	098-1434	1	Bolt, 1/4-20 x 2", HH, SS
21	098-2507	3	Locknut, 1/4-20, SS
Rep.	088-1063	0	Pump assembly Through Impeller
			(Needs Gasket 089-6303)




#### 063-0800 Control System Assembly 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	081-6421	1	Control Box Weldment
2	086-6678	4	Control Box Hinge
3	086-6676	1	Safety Latch
4	086-6317	1	Shelf Handle
5	098-1204	13	Screw, 8-32 x 1/2" RH, Slotted
6	098-2201	9	Locknut, 8-32, Hex
7	098-2404	1	Washer, ¼", SS
8	064-0010	3	Chemical Pump Assembly, External
9	083-6404	1	Chemical Discharge Tube, Red 5'
9	083-6405	1	Chemical Discharge Tube, Green 5'
9	083-6406	1	Chemical Discharge Tube, Blue 5'
10	083-6408	1	Chemical Suction Tube, Red 8'
10	083-6409	1	Chemical Suction Tube, Green 8'
10	083-6410	1	Chemical Suction Tube, Blue 8'
11	083-6407	3	Tube Stiffener
12	089-9223	3	Decal, Prime
13	089-9226	1	Decal, Timer Cam
14	089-9237	1	Decal, Start-Fill
15	091-3001	1	Switch, Black Fill
16	091-3002	1	Switch, Red Start
17	091-3083	1	Contactor
18	091-3008	2	Master Switch
19	091-3009	3	Prime Switch
20	091-3049	1	Counter, Electric
21	091-3051	1	Timer, 90 Sec. 7 Cam
22	091-4019	1	Plastic Plug
23	091-5028	1	Wiring Harness
24	091-7006	1	Red Light, Indicator




#### 063-0800 Control System Assembly 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
25	092-1008	1	½" Close Nipple
26	092-1029	1	½" x 3/8" Reducer, Brass
27	092-1030	1	Fitting, 3/8" Comp x 1/2" FPT 90°
28	098-1606	3	Tube Clamp
29	091-3060	1	Toggle Switch
30	091-4016	1	Junction Box
31	091-4004	1	Cover, Junction Box
32	091-5156	1	Conduit, ½", 240"
33	091-4141	5	Conduit, Fitting ½" ST
34	091-3059	1	Relay, Auto Start
35	086-6419	1	Chemical Discharge Bracket, 5-CD
36	098-1414	2	Screw, 1/4-20 x 1/2", TH, SS
37	091-4015	3	Grommet, Chemical Feeder Assembly
38	093-1043	3	Hose Barb 3/16"
39	087-6433	1	Control Box Cover
40	096-1002	1	Control Box Lock and Key
41	089-9204	1	Outside Sump Cleaning Instruction
42	089-9277	1	NSF Sticker
OPT.	091-3003	1	Relay, Instant Start
N/S	089-0001	1	Nameplate
N/S	089-0050	1	NSF UL Plate
N/S	098-9011	6	Pop Rivets
N/S	089-9202	1	Wiring Diagram
N/S	089-9210	1	Decal, Connect to Power Supply
N/S	089-9227	1	Adjust Cam Decal
N/S	089-9257	1	Decal, Deliming, Caution
N/S	091-4142	3	Conduit, Elbow, ½" 90°
N/S	091-4017	1	Grommet, Large
N/S	091-5213	2	Red Butt Connector
N/S	091-5220	6	Cable Tie, Medium
N/S	091-5223	1	Molex Housing, Male
N/S	091-5224	1	Male Molex Pin
N/S	091-5226	8	Tabs, Master Switch




#### 063-0800 Control System Assembly 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
N/S	091-5247	1	Spade Connector, Female
N/S	091-6157	8	Flag Connector and Cover
N/S	098-1102	4	Screw, 6-32 x 1/4", RH, SS
N/S	098-1104	4	Screw, 6-32 x 1/2", RH, SS
N/S	098-1205	8	Screw, 8-32 x 5/8", RH, SS
N/S	098-1211	4	Screw, 4-40 x 1/4", RH, SS
N/S	098-1418	1	Bolt, 1/4-20 x 1", TH, SS
N/S	098-1420	1	Screw, 1/4-20 x 1 1/4", TH
N/S	098-2001	4	Locknut, 4-40
N/S	098-2101	4	Nut, 6-32, SS, Hex
N/S	098-2202	8	Nut, 8-32, SS, Hex
N/S	098-2507	1	Locknut, 1/4-20
N/S	098-9020	1	Plastic Plug, 7/8"
N/S	292-1006	2	Locknut, 1/2" FPT, Brass
N/S	098-2507	5	Locknut, 1/4"
N/S	091-3011	1	Sock, Relay
N/S	091-4002	1	Grommet
N/S	091-9103	1	Relay Cap
N/S	091-5156	1	Conduit, ½", 240"




#### 064-0010 Chemical Pump Assembly 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	091-1002	1	Gear Motor
2	083-6703	1	Pump Housing, 3D
3	067-6702	1	Rotor Assembly, 3D
3A	083-6704	1	Rotor, 3D, Chem. Pump
3B	083-6705	2	Roller, 3D, Chem. Pump
3C	083-6706	2	Pin, 3D, Chem. Pump
3D	098-1322	1	Set Screw, 10-32 x 1/4"
4	087-6700	1	Squeeze Tube
5	083-6707	1	Cover, 3D, Chem. Pump
6	098-1606	2	Tube Clip, Chem. Pump Squeeze Tubes
7	091-5222	0	Molex Female Pin
8	091-5221	0	Molex Cover, Female Housing
9	098-1305	2	Screw, RH, 10-32 x 1 ½"
10	098-1204	3	Screw, RH, SS, 8-32 x 1/2"
11	098-1321	1	Screw, RH, SS, 10-32 x 1 3/4"
12	091-5224	2	Molex Male Pin
13	091-5223	2	Cover, Housing, Male Molex
14	092-1146	2	Hose Barb, 1/4" x 3/16"
			(Connects Squeeze Tube to 1/4" Chem. Tubing)




#### 065-0100 Fresh Water Plumbing Assembly 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	385-6121	1	Air Gap Weldment, 5-AG-S
2	092-3119	1	Fresh Water Supply Tube, 5-AG-S
3	092-1147	1	Fitting, 3/4" MPT x 5/8" Comp. 90 Deg. Elbow
4	089-7001	1	Solenoid Valve, 3/4"
5	092-1074	2	Fitting, 3/4" Street Elbow, 90°
6	092-9006	1	Y-Line Strainer, 3/4"
7	092-5055	1	Shut-Off Valve, ¾"
8	092-1073	2	Nipple, 3/4" Close
9	389-6603	1	Gasket, Air Gap
10	098-1426	4	Bolt, 1/4-20 x 3/4", HH, SS
11	098-9027	1	U-Bolt, 1/4-20, SS
12	086-6647	1	Bracket, Plumbing, 5-AG-S
13	098-2507	6	Locknut, 1/4-20, SS
14	098-2404	8	Washer, ¼", SS
N/S	092-9008	Rep.	Screen (Replacement), 3/4"
N/S	385-6124	1	Air Gap Flanged Outlet Elbow Weldment, 5-AG-S
Rep	092-5020	0	Solenoid Valve Repair Kit (Replacement), ¾
Rep	092-5026	0	Solenoid Valve Body (Replacement), 3/4
Rep	092-5017	0	Solenoid Valve Coil (Replacement)



#### 066-1700/066-1800 Drain System Assembly LF/RF 5-CD


Ref.		No.	
No.	Part No.	Req.	Description
1	092-1030	2	Conduit Fitting, ¼", 90 Deg.
2	086-6734	1	Conduit, 3/8" O.D., LF
2A	086-6735		Conduit, 3/8" O.D., RF
3	085-6620	1	Solenoid Base, Outside Sump
4	085-6622	1	Solenoid Base Plate
4A	085-6634		Solenoid Base Weldment, RF
5	098-2404	10	Washer, 1/4", SS
6	098-1423	4	Bolt, HH, SS, 1/4-20 x 1/2"
7	098-2507	4	Locknut, SS, 1/4-20
8	091-4005	1	Grommet, Plastic, ½"
9	098-1413	2	Bolt, 1/4-20 x 3/8", TH, SS
10	091-2001	1	Solenoid
11	098-2201	1	Locknut, 8-32, SS
12	098-1205	1	Screw, RH, SS, 8-32 x 5/8"
13	086-6607	1	1-1/16 Slotted Washer (Large)
14	098-3001	1	Spring, Drain Solenoid, Outside Sump
15	086-6605	1	Link, Drain Solenoid, Outside Sump
16	086-6606	1	1-5/16 Slotted Washer (Small)
17	085-6618	1	Solenoid Cover, LF
17A	085-6635		Solenoid Cover, RF
18	089-6610	1	Chain, Drain, Make From 098-9001
19	098-2201	1	Locknut, 8-32, SS
20	098-1205	1	Screw, RH, SS, 8-32 x 5/8
21	084-6622	1	Chain Cover, Make From 093-1012
22	098-2301	5	Locknut, SS, 10-32
23	098-1311	1	Screw, RH, SS, 10-32 x 1 3/8
24	081-6601	1	Drain Plug Assembly, 1 ½", Outside Sump
Rep	084-6608	0	Drain Tube (Replacement Part)
Rep	083-6601	0	Drain Ball (Replacement Part), 1 ½"
25	085-6636	1	Sump Screen
26	089-6601	1	Sump Gasket
27	098-1423	6	Bolt, HH, SS, 1/4-20 x 1/2
28	085-6204	1	Sump Assembly With Tail Piece
29	299-1005	1	Temperature Gauge



#### 066-1700/066-1800 Drain System Assembly LF/RF 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
30	089-6602	2	Drain Elbow Gasket
31	086-6601	1	Drain Seat, 1 ½"
32	085-6199	1	Drain Elbow Weldment
33	098-1508	6	Bolt, 5/16-18 x 5/8", HH, SS
34	092-1029	1	Reducer Bushing, ½" x 3/8"
35	091-4144	1	Conduit Locknut
36	085-6160	1	Drain Screen Secondary (To Protect The Pump)
37	098-9028	1	Washer, Rubber Reinforced
38	098-2404	1	Washer, ¼", SS
39	098-2507	1	Locknut, 1/4-20, SS
N/S	086-6615	1	Water Fin, Outside Sump
40	092-1091	1	Fitting, 3/8" Comp x 3/8" MPT
N/S	092-1124	1	Locknut, 3/8" MPT

#### 067-1400/067-1500 Door Actuator Assembly LF/RF 5-CD



#### 067-1400/067-1500 Door Actuator Assembly LF/RF 5-CD

Ref.		No.	
No.	Part No.	Req.	Description
1	085-6701	2	Spring Extension
2	098-4002	2	Bushing, Bronze
3	098-1510	2	Bolt, 5/16 x 1 1/4", HH, SS
4	098-2502	2	Nut, 5/16-18, HH, SS
5	385-6119	1	Arm Support Bracket, LH
N/S	085-6184	2	Arm Support Bracket, RH
6	098-1423	4	Bolt, 1/4-20 x 1/2", HH, SS
7	098-2404	4	Washer, ¼", SS
8	098-2507	4	Locknut, 1/4-20, SS
9	085-6729	1	Door Operating Arm (Lever Arm), RF
9	085-6730	1	Door Operating Arm (Lever Arm), LF
10	098-1434	2	Bolt, 1/4-20 x 2", HH, SS
11	098-2404	6	Washer, ¼", SS
12	084-6703	4	Bushing (Dowel 3/8")
13	086-6701	2	Door Stop
14	098-1432	2	Bolt, 1/4-20 x 1 3/4", HH, SS
15	084-6702	2	Spacer, Door
16	086-6728	1	Door Link, Long
17	098-2405	4	Cap Locknut, 1/4-20, SS
18	098-3003	2	Door Spring, 8 ½" Long
19	086-6731	2	Spring Extension, Secondary
20	098-1581	2	Eye Bolt, 5/16-18 x 6"
21	098-2502	2	Nut, 5/16-18, HH, SS
22	092-1086	2	Lever Arm End Cap, 1"
23	086-6729	1	Door Link, Bent
24	084-6241	1	Door Slide Rod
25	086-6732	2	Bracket, Door Slide Rod
26	098-2708	2	Locknut, 3/8-16 Nylon, SS
27	084-6242	1	Door Slide
28	098-2501	2	Locknut, 5/16-18, SS
29	098-1517	2	Bolt, 5/16-18 x 3/4" Lg. TH, SS
N/S	086-6733	1	Door Stop (Front Door), 5-CD
N/S	098-2511	1	Washer, 5/16" I.D. 1" O.D., SS
30	098-2705	4	Washer, 7/16" I.D. x 1" O.D., SS
31	098-1445	2	Bolt, 1/4-20 x 1", HH, SS

Manufacturer of low and high temperature Commercial Dishwashers and Glasswashers

900 Blake Street Edwardsville, Kansas 66111

Ph:(913) 422-3700

Fax:(913) 422-6630